


DIAGRAM OF OS156-B1



ITEM NO.	PART NO.	DESCRIPTION	ITEM NO.	PART NO.	DESCRIPTION	ITEM NO.	PART NO.	DESCRIPTION
101	12201-0113001-2	HOUSING	323	12247-0010171-1	6*PAD W/O HOLE HOOK			
201	12304-0114701-2	REGULATOR	324	12340-0014701-1	HEAT ISOLATION WASHER			
202	12305-0110001-1	VALVE STEM	328	1233M-0110001-1	BEARING SEAL			
203	2041109-01040-0	O - RING	329	12332-0110001-1	DUST COVER			
204	2041109-01050-0	O - RING	330	2041109-03070-0	O - RING			
205	2040400-04070-0	SPRING PIN	401	12327-0010001-1	MUFFLER SCREW			
206	12306-0014701-1	SEAL	402	12351-0112501-1	MUFFLER			
207	12307-0014701-2	TIP VALVE	403	12328-0014701-1	MUFFLER CAP			
208	12308-0014701-1	CONICAL SPRING						
209	12309-0014703-1	AIR INLET						
210	2040400-05180-0	SPRING PIN						
211	12310-0114701-4	TRIGGER						
301	12311-0014701-1	FRONT RING						
302	2041200-00093-0	BEARING						
303	12312-0110001-1	FRONT BEARING PLATE						
304	12313-0110001-1	ROTOR						
305	12314-0110001-1	BLADES						
306	12315-0110001-1	CYLINDER						
307	2040401-05230-0	LINE-UP PIN						
308	12316-0110001-2	REAR BEARING PLATE						
309	2041200-00055-0	BEARING						
310	12317-0114701-1	REAR RING						
311	12319-0014701-1	MIDDLE RING						
313	12321-0110001-1	LOCK RING KEY						
314	12322-0014714-1	MOTER SHAFT BALANCER						
315	2040701-01010-0	ROTOR KEY						
316	2041201-00010-0	BEARING						
317	12323-0014701-1	BEARING SHIELD						
318	2040301-10010-0	SNAP RING						
319	12324-0014701-1	BALANCER SHAFT						
320	12325-0014701-1	SHROUD						
321	2040303-40010-0	SNAP RING						
322	12350-0010001-1	BEARING SEAL						