


DIAGRAM OF IT350-A1



ITEM NO.	PART NO.	DESCRIPTION	ITEM NO.	PART NO.	DESCRIPTION	ITEM NO.	PART NO.	DESCRIPTION
101	2040100-03010-2	BOLT ASSY	403	12226-0074701-1	TIP VALVE			
102	12318-0100901-1	HAMMER CASE	405	12346-0074701-1	EXHAUST DEFLECTOR			
103	1230K-0080003-1	HAMMER CASE BUSHING	406	12309-0014701-2	AIR INLET			
104	1230F-0100001-1	HAMMER CASE PILOT	407	12225-0074701-2	TRIGGER UNIT			
105	1230S-0100003-1	HAMMER CASE GASKET	408	12351-0070001-1	MUFFLER			
106	2040306-00021-0	SOCKET RETAINER	409	2041104-02070-0	O - RING			
107	2041100-02030-0	O - RING	417	1230K-0070007-3	BUSHING			
108	1230D-0080002-1	ANVIL						
108A	12227-0080014-2	ANVIL						
109	1230B-0070001-1	HAMMER FRAME PIN						
110	1230C-0070001-1	HAMMER						
111	1230E-0100001-1	HAMMER FRAME						
112	12340-0104701-1	WASHER						
201	12302-0106609-1	HOUSING						
202	1230N-0070901-2	HANDLE GRIP						
203	1230S-0070001-1	HOUSING GASKET						
204	1230L-0070002-1	REVERSE VALVE						
205	2041104-03030-0	O - RING						
206	12223-0070901-1	REAR COVER UNIT						
207	1230M-0074701-1	LEVER						
208	2040800-01010-0	STEEL BALL						
209	1230J-0070002-1	SPRING						
210	2040100-03030-2	BOLT ASSY						
301	2041200-00056-0	BEARING						
302	12312-0100001-1	FRONT BEARING PLATE						
303	12315-0100001-2	CYLINDER						
304	12313-0100001-3	ROTOR						
305	12314-0100001-2	BLADES						
306	12316-0074701-1	REAR BEARING PLATE						
307	1230B-0100001-1	PIN						
308	2041200-00088-0	BEARING						
401	1230K-0070001-1	INSERT BUSHING						
402	12319-0070001-3	SEAL						